



**Part Number: 134-1002**

**Application: CHEVY LS CAM RETAINER BOLT  
KIT**

### **Installation Procedure**

1. Clean and inspect all hardware prior to installation. Look for obvious defects or shipping damages. Please call 805-339-2200 with any questions or issues.
2. To ensure proper engagement and accurate torque readings, clean the female threads.
3. Lubricate the bolt threads and underside of the bolt head with ARP Ultra-Torque Fastener Assembly Lubricant.
4. Torque the bolts using a crisscrossing pattern to

**25 ft-lbs**

If you have any questions or need additional information please contact us at (805) 339-2200 or by FAX at (805) 650-0742

Automotive Racing Products  
1863 Eastman Ave. Ventura, Ca 93003

[www.arp-bolts.com](http://www.arp-bolts.com)