



1863 Eastman Ave.
Ventura, Ca. 93003
www.arp-bolts.com

Part Number: 156-1004 & 156-1005

Application: FORD 5.0L COYOTE V8

Cam Tower Bolt - Installation

- [1] Please check the part-number(s) for your application against the part-number(s) listed on the instruction sheet.
- [2] Clean and inspect all hardware prior to installation. Look for obvious defects or shipping damages, plus proper fit, length and dimension.
- [3] Install the camshafts, the camshaft caps and the timing gears (if removed) as described in the factory service manual.
- [4] Lubricate the threads of the bolts and the washers with **ARP Ultra-Torque Fastener Assembly Lubricant**.
- [5] Install the bolt(s) and tighten them hand tight.
- [6] Following the manufacturer's recommended torque sequence tighten the bolts to 90 in-lbs using **ARP Ultra-Torque Fastener Assembly Lubricant**.

If you have any questions or need additional information please contact us at **(805) 339-2200** or by FAX at **(805) 650-0742**