



Part Number: 258-2501

Application: Ford Godzilla 7.3L ARP2000

Balancer Bolt Installation

1. Clean and inspect all hardware prior to installation. Look for obvious defects or shipping damages. Please call 805-339-2200 with any questions or issues.
2. To ensure proper thread engagement and accurate torque reading, clean the female threads in the crankshaft. Chase, if necessary, with a thread chaser.
3. Lubricate both sides of the washer with ARP Ultra-Torque Fastener Assembly Lubricant then place onto the bolt.
4. Lubricate the bolt threads with ARP Ultra-Torque Fastener Assembly Lubricant.
5. Install the bolt, tightening by hand until the washer and bolt contact balancer face.
6. Torque the bolt to: **125 FT-LBS + 90°**

If you have any questions or need additional information please contact us at (805) 339-2200 or by FAX at (805) 650-0742

Automotive Racing Products
1863 Eastman Ave. Ventura, Ca 93003

www.arp-bolts.com